













**SAFETY INSTRUCTIONS**

1. Do not attempt to operate this machine until you are properly trained.
2. Read the manual carefully before using the machine.
3. Do not touch the rotating parts of the machine while it is running.
4. Do not touch the hot surfaces of the machine while it is running.
5. Do not touch the hot surfaces of the machine while it is running.
6. Do not touch the hot surfaces of the machine while it is running.
7. Do not touch the hot surfaces of the machine while it is running.
8. Do not touch the hot surfaces of the machine while it is running.
9. Do not touch the hot surfaces of the machine while it is running.
10. Do not touch the hot surfaces of the machine while it is running.

**ΠΡΟΣΟΧΗ**

- Χρήση σε εξωτερικό χώρο μόνο
- Διαβάστε προσεκτικά τις οδηγίες χρήσης
- Οι επιδείξεις ενέργειας να είναι κατά θερμοίς
- Κρασίστε τα παιδιά μακριά
- Μην μετακινείτε κατά τη διάρκεια της χρήσης

CE 0063

**ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ:**

1. Έχετε ανοιχτό το καπάκι όταν ανάψετε τους καυστήρες
2. Γυρίστε όλους τους διακόπτες στη θέση OFF
3. Προσαρμόστε τον ρυθμιστή πίεσης στη φιάλη βαλβίδα της φιάλης
4. Πιέστε τον διακόπτη και ταυτόχρονα γυρίστε αριστερόστροφα στη θέση HIGH. Θα ακουστεί ένα «κλικ» και θα γίνει η ανάφλεξη του καυστήρα.
5. Εάν ο καυστήρας δεν ανάψει, γυρίστε τον διακόπτη στη θέση OFF περιμένετε περίπου 5 λεπτά και επαναλάβετε το βήμα 4.
6. Επαναλάβετε για να ανάψετε και τους άλλους καυστήρες